This information is intended for Europe (230/240V) only and does not apply to North America!

230 V GREY

SEBO MADE IN GERMANY

SEBO 370 COMFORT



Pos.	Part.-No.	Description
1	1037 EH	Handle grip, compl. incl. Pos.2
2	1596 HG	Handle cover
3	0127 ER	Screw M 4x10k
4	1870 dg	Cable with Contour-plug
4	1871 dg	Cable with CH-plug
5	1848	Handle cpl.
6	1831 hg	Dust bag housing
7	1835 dg	Internal cover 370/470
8	5289	Seal
9	5043	Seal
10	5424 ER	Retaining ring
11	1823 hg	Attachment clip
12	5359 HE	Grommet 10pcs, light grey
13	0502	Terminal block 2-wire
14	1030 UL	Cable clamp
15	1812 hg	Cover
16	1814 hg	Carryng handle
17	5146	Stop spring
18	1813 hg	Cable hook
19	1859 dg	Handle catch
20	0161 ER	Clip 4
21	0850 dg	Locking catch
22	1811	Locking rod
23	1012 N	Terminal block compl.
24	1807 hg	Connector
25	1836	Female contakt holder
26	1851	Sound insulation
27	1047	Vac motor seal
28	1844	Vav motor 230V/1000W
28a	05118 S	Carbon brush set
29	1821	Motor cover
30	1822-1	Motor support
31	1027	Leaf spring
32	1073	Clamp
33	1824	Connecting rod
34	1825	Motor filter
35	1934 ER	Print.circ.board 230/240V
36	1860	Fitting
37	1852 hg	Suction pipe cover
38	1869 hg	Lens, bag light indicator
39	1830 dg	Switch button
40	1862	Spring
41	1833	Internal cable (230/240V)
42	1878	Exhaust filter
43	1802 hg	Exhaust filter cover
44	1853 SE	Motor cover
45	1804 hg	Dust bag housing bumper
46	1846 hg	Front cover complete
47	1818 dg	Cover release
48	6040	Seal, cover release
49	1819	Bearing cover
50	1847	Bag holder, compl.
51	5091	Safety catch spring
52	1817	Safety catch
53	5093 N	Dust bag/pack 1 pcs.
54	5045 dg	Extension tube
55	5040 sb	Hose compl.
56	1491 dg	Upholstery nozzle
57	1092 dg	Crevice nozzle
58	0102 ER	Screw F 3,9x13
59	0103 ER	Screw F 3,9x16
60	1875	Micro/Hosp.-filter
61	1884 hg	Retaining button

Art.-No. 06252A2, 08/2013

This information is intended for Europe (230/240V) only and does not apply to North America!

230 V GREY

SEBO MADE IN GERMANY

SEBO 370 COMFORT



Pos.	Part.-No.	Description
100	**20200hg**	Chassis
101	**20204ER**	Front base plate
102	**20109ER**	Bumper
103	**20115**	Wire tie
104	**20107ER**	Rear base plate
105	**20230ER**	Foot pedal cpl.
105a	**20140ER**	Axle
106	**20136ER**	Swivel bearing
107	**2306HG**	Wheel
108	**2014 ER**	Axle clamp
109	**20126ER**	Pile adjustment axle
110	**2608hg**	Pile adjustment wheel
111	**2833**	Trust member
112	**20128ER**	Pile adjustment knob
113	**4019**	Spring
114	**2975ER**	Brush motor 220-240V, 175W
114a	**05141S**	Carbon brush set
115	**2319**	Motor pulley
116	**2923**	Belt
117	**20232ER**	Swivel neck cpl.
118	**0895ER**	Wire swivel neck 2-wire
119	**2602hg**	Swivel neck cover
120	**20217ER**	Swivel support r.h.
121	**20218ER**	Swivel support l.h.
122	**0897ER**	Micro switch incl. wire
124	**1073**	Clamp
125	**2919ER**	Brush roller pulley
126	**20163ER**	PCB 220/230V, 175W
127	**4098ER**	Brush roller cpl.
128	**2046**	Brush strip
129	**20123ER**	Bearing block l.h.
130	**20117ER**	Bearing block r.h.
131	**20120ER**	Brush cover release
131a	**20121ER**	Spring
132	**2653hg**	Support lever with spring
133	**2651**	Return spring
134	**20226dgSE**	Power head cover cpl.
135	**20118ER**	Brush strip cover
136	**01017ER**	Screw 4x20
137	**0197ER**	Screw 4x12
138	**01036ER**	Screw 4x14
139	**0176ER**	Screw 4x30
140	**0102ER**	Screw 3.9x13
141	**20124ER**	Access door cpl.
142	**20127ER**	**Pile** adjustment lever
143	**20129ER**	Mounting cap